

Dual IC Buffer Instructions

Version 2014July27 Copyright 2013 JD Sleep
Permission refused for posting/serving this file from any site other than www.generalguitargadgets.com
Trademarks are property of their owners





This is an implementation of the IC Buffer that we have, but contains two identical buffers on a single PCB. We did this to consolidate and save a lot of wiring and space when you have a need for two or more buffers in the same enclosure.

Here are some of the options available with this PCB:

- It can be used with one input and two outputs as a splitter with both outputs separately buffered
- It can be used with two input and two outputs to buffer two completely independent signal chains.
- Two of the PCBs can be used to build a 4-way splitter as the photo above shows.
- There are two on-board LED current-limiting resistors that can be used in a buffered switching box (with indicator LEDs). These can be connected to ground or 9v+ depending on your switching needs. This feature will also eliminate some tedious off-board wiring. This is used in the buffered ABY switch box pictured above.

The resistors all stand on-end as shown in the photos below. It is very easy to build. Use the wiring diagram examples on this project page or create you own customized uses!


Note: The screen print on The first run of PCBs has pad O1 and O2 labels reversed. Follow the layout diagrams if you are building a version that has two inputs.

Here's an inside view of the units we built to give you some general ideas if needed.



Dual IC Buffer Instructions

Version 2014July27 Copyright 2013 JD Sleep
Permission refused for posting/serving this file from any site other than www.generalguitargadgets.com
Trademarks are property of their owners



Comments and questions are welcome and can be sent to info@generalguitargadgets.com